


印刷封面 135mm




Genius web : www.geniusnet.com
OEM/ODM : www.kyec.com

KYE Systems Corp.
#492, Sec. 5, Chongxin Rd., Sanhong Dist.,
New Taipei City 24160, Taiwan
Tel: 886-2-2995-6645
Fax: 886-2-2995-6649
Email: sim@geniusnet.com.tw
Email: csd@geniusnet.com.tw (Tech. Support)
http://www.geniusnet.com

SlimStar Q200 Stylish Multimedia Keyboard



12 Multimedia FN keys



12030089400-A

Multi-language Quick Guide

Replace Batteries

If the mouse or keyboard does not work properly, then the batteries have lost their charge, so you need to replace them.

Warning : do not mix or use different types of batteries at the same time.

Notes on Battery Usage

When you use the battery, carefully read and strictly observe the Safety Instructions and the notes described below :

- Different battery types and surrounding temperatures may affect the battery performance.
- Avoid using batteries in extremely cold environments as low temperatures can shorten the battery life and reduce wireless device performance.
- If you are using a new rechargeable battery or rechargeable battery that has not been used for an extended period of time (batteries that pass the expiry date are exceptions) it might affect the period of time according to local regulations.
you can use this device. Therefore, to maximize their performance and lifetime, we recommend that you fully charge the batteries and discharge them for at least one complete cycle before use.
- The battery or wireless device may feel warm when using for an extended period of time. This is normal and not a malfunction.
- If you will not be using the batteries for an extended period of time, remove them from the wireless device to prevent leakage or corrosion.
- Always keep the terminals in a clean state.
- Risk of explosion if battery is replaced by an incorrect type.
- Dispose of used batteries according to local regulations.

English

Keyboard function key definition

	Fn + F1	Media Player
	Fn + F2	Volume -
	Fn + F3	Volume +
	Fn + F4	Mute
	Fn + F5	Previous
	Fn + F6	Track
	Fn + F7	Play / Pause
	Fn + F8	Stop Playing
	Fn + F9	Web / Homepage
	Fn + F10	Email
	Fn + F11	My computer
	Fn + F12	My favorite

Deutsch

Tastaturfunktionstastendefinition

	Fn + F1	Media Player
	Fn + F2	Lautstärke -
	Fn + F3	Lautstärke +
	Fn + F4	Stumm
	Fn + F5	Vorheriger
	Fn + F6	Nächster
	Fn + F7	Wiedergabe / Pause
	Fn + F8	Wiedergabe stoppen
	Fn + F9	Webbrowser
	Fn + F10	Email
	Fn + F11	Mein Computer
	Fn + F12	Mein Favorit

Français

Définition de la touche de fonction du clavier

	Fn + F1	Lecteur multimédia
	Fn + F2	Volume -
	Fn + F3	Volume +
	Fn + F4	Sourdine
	Fn + F5	Précédent
	Fn + F6	Suivant
	Fn + F7	Lecture / Pause
	Fn + F8	Arrêt de la lecture
	Fn + F9	Navigateur
	Fn + F10	Email
	Fn + F11	mon ordinateur
	Fn + F12	mon préféré

Italiano

Definizione del tasto funzione tastiera

	Fn + F1	Media Player
	Fn + F2	Volume -
	Fn + F3	Volume +
	Fn + F4	muto
	Fn + F5	Precedente
	Fn + F6	Prossimo
	Fn + F7	Riproduzione / Pausa
	Fn + F8	Ferma Riproduzione
	Fn + F9	Web Browser / Home
	Fn + F10	E-mail
	Fn + F11	Il mio computer
	Fn + F12	Il mio preferito

Español

Definición de la tecla de función del teclado

	Fn + F1	Reproductor multimedia
	Fn + F2	Volume
	Fn + F3	Volume +
	Fn + F4	Silencio
	Fn + F5	Anterior
	Fn + F6	Siguiente
	Fn + F7	Reproducir / Pausar
	Fn + F8	Pausar reproducción
	Fn + F9	Navegador de Internet
	Fn + F10	Correo electrónico
	Fn + F11	Mi computadora
	Fn + F12	Mi favorito

Brasil

Definição da tecla de função do teclado

	Fn + F1	Tocador de Mídia
	Fn + F2	Volume -
	Fn + F3	Volume +
	Fn + F4	Mudo
	Fn + F5	Anterior
	Fn + F6	Próximo
	Fn + F7	Play / Pausa
	Fn + F8	Parar Reprodução
	Fn + F9	Navegador Web
	Fn + F10	E-mail
	Fn + F11	Meu computador
	Fn + F12	Meu favorito

Česky

Definice funkční klávesy na klávesnici

	Fn + F1	Media Player
	Fn + F2	Hlasitost -
	Fn + F3	Hlasitost +
	Fn + F4	Ztlumení zvuku
	Fn + F5	Předchozí
	Fn + F6	Další
	Fn + F7	Přehrát / Pauza
	Fn + F8	Ukončení přehrávání
	Fn + F9	Internetový prohlížeč
	Fn + F10	Email
	Fn + F11	Můj počítač
	Fn + F12	Můj oblíbený

